


metabo®

BS 18 LT



0002	7x	141	113	180
0004	1x	316	049	970
0006	2x	141	122	220
0008	1x	317	004	160
0009	1x	316	050	450
0010	1x	343	431	110
0011	1x	342	021	670
0012	1x	343	430	890
0014	1x	343	397	990
0015	1x	343	394	790
0016	1x	343	409	750
0017	1x	338	058	350
0025	1x	143	160	080
0026	1x	343	083	380
0027	1x	316	052	120
0028	1x	338	123	840
0030	1x	316	052	130
1001	1x	338	504	870

